

CBM3 AXLE LOCKING PIN INSTRUCTIONS

As an owner of the Concourse CBM3 Push Buggy you will not need to fit different axles (as opposed to other push buggy models). The Smart Wheels will connect directly to the CBM3 axle, however, you do require locking pins to secure the central hub of the Smart Wheels so the outer drives your buggy.

Before installing the CBM3 axle locking pins, please ensure you position your buggy in a safe and stable manner then remove the two large free spinning wheels.

1.0 Enclosed you will find two locking pins and a 3mm allen key as shown below.



2.0 You will notice a hole [as shown below] to thread the locking pin screw through using the allen key.



On the opposing side hold the locking pin so it threads smoothly until it's firmly in position.



Repeat this process with the opposite side of the CBM3 buggy. Please note that the locking pins will suit either side of the buggy.

Once secure you can fit each of the Smart Wheels to the axles, ensuring the locking pin lines up with then insert into position with the Smart Wheel's hub as per the sequence below.

