

# CBM3

## INSTRUCTION MANUAL

---

# SCORECARD HOLDER UPGRADE



VERSION 1.0

 **CONCOURSE**  
CONQUER THE COURSE



## CBM3 SCORECARD HOLDER UPGRADE INSTRUCTIONS

1. Remove existing CBM3 Scorecard Holder. Refer to image below.



2. Drill out original CBM3 Scorecard Holder holes to 3mm and repeat this both sides. Refer to image below.



3. Tie a knot at one end of the new elastic cord supplied and pass through one of the holes that has been drilled out to 3mm. Refer to images below.



4. Pull elastic cord through the opposite hole as per images below and pull very tight.



5. Once elastic cord has been pulled through tightly, tie a knot to secure the cord. Refer to image below.



6. Cut off excess cord as per image below.

